

**Assembly Instructions
FJ 40 Land Cruiser
Transfer Case Parking Brake**

Installation Instructions

1. Remove drum parking brake parts. Machine drum off of the splined yoke assembly. Leave a flange of about 4 9/16.

2. Install the bracket using the 4 socket head screws. Use a lock washer on the upper left one as it has a short blind hole.

2. Reinstall the splined yoke with the rotor mounted to it. Use the 7/16-20 bolts pointing to the rear as the space is limited on the front side.

3. Install the caliper.

4. Hook up the cable using the clevis to connect to the caliper arm.

5. Adjust the parking brake travel at the front end of the cable.