

Assembly Instructions

205 Transfer Case Parking Brake

Installation Instructions

1. Install the rotor on the backside of the yoke using Girdles, Socket Head Bolts and Lock Washers

2. Bolt the bracket to the case. Seal the threads on the bolts into the case if there is any chance of oil leakage.

3. Mount the caliper to the transfer case bracket. Use some 7/16 Flat Washers between the caliper and bracket for good rotor clearance.