

Assembly Instructions Divco Parking Brake

Installation Instructions

1. Install the rotor on the backside of the yoke using the Girdles, 3/8 bolts and nuts.
2. Bolt the bracket to the case using the 3/8 – 16 bolts and lock washers.
3. Install the caliper to the bracket. Use the extra 7/16 washers to space the caliper in relation to the rotor.